

Външно тяло	RXF60D5V1B9		
Вътрешно тяло	FTXF60F2V1B		
Function			
Охлаждане	Да		
Отопление	Да		
	Average (mandatory)		
	Warmer (if designated)		
	Colder (if designated)		
	Да		
	Да		
	Не		
Item	Symbol	Value	Тяло
Design Load			
Oхлаждане heating / Average	Pdesignc	6	kW
heating / Warmer	Pdesignh	4.8	kW
heating / Colder	Pdesignh	2.59	kW
	Pdesignh	2.85	kW
	Pdesignh	2.39	kW
Обявен капацитет* за охлаждане при вътрешна температура 27(19) °C и външна температура Tj			
Tj = 35°C	Pdc	6	kW
Tj = 30°C	Pdc	4.43	kW
Tj = 25°C	Pdc	2.85	kW
Tj = 20°C	Pdc	2.39	kW
Declared capacity* for heating / Average season , at indoor temperature 20 °C and outdoor temperature Tj			
Tj = -7°C	Pdh	4.25	kW
Tj = 2°C	Pdh	2.59	kW
Tj = 7°C	Pdh	1.67	kW
Tj = 12°C	Pdh	2.03	kW
Tj = Bivalent temperature	Pdh	4.25	kW
Tj = operating limit	Pdh	4.21	kW
Declared capacity* for heating / Warmer season , at indoor temperature 20 °C and outdoor temperature Tj			
Tj = 2°C	Pdh	2.59	kW
Tj = 7°C	Pdh	1.67	kW
Tj = 12°C	Pdh	2.03	kW
Tj = Bivalent temperature	Pdh	2.59	kW
Tj = operating limit	Pdh	4.22	kW
Declared capacity* for heating / Colder season , at indoor temperature 20 °C and outdoor temperature Tj			
Tj = -7°C	Pdh		kW
Tj = 2°C	Pdh		kW
Tj = 7°C	Pdh		kW
Tj = 12°C	Pdh		kW
Tj = Bivalent temperature	Pdh		kW
Tj = operating limit	Pdh		kW
			Tj = -15°C
Bivalent temperature			
heating / Average	Tbiv	-7	°C
heating / Warmer	Tbiv	2	°C
heating / Colder	Tbiv	0	°C
Cycling interval capacity			
for cooling	Pcyc		kW
for heating	Pcyh		kW
Degradation co-efficient cooling**	Cdc	0.25	-
Electric power input in power models other than 'active mode'			
Off mode	Poff	0.001	kW
Standby mode	Psb	0.001	kW
Thermostat-off mode	PTO	0	kW
Crankcase heater mode	PCK	0	kW
Annual electricity consumption			
Oхлаждане	QCE	342	kWh/a
heating / Average	QHE	1654	kWh/a
heating / Warmer	QHE	702	kWh/a
heating / Colder	QHE		kWh/a
Capacity control			
fixed	N		
staged	N		
variable	N		
Contact details for obtaining more information	Daikin Europe N.V. Zandvoordestraat 300, B-8400 Oostende, Belgium		

* for staged capacity units, two values divided by a slash (/) will be declared in each box in the section 'Declared capacity of the unit' and 'Declared EER/COP' of the unit.

** if default Cd = 0.25 is chosen then (results from) cycling tests are not required. Otherwise either the heating or cooling cycling test value is required.